



Installation and set up to be carried out in a safe and suitable manner by the necessary skilled personnel – please see “PDU Installation Guide” for further information.

**Please Note:** To ensure correct operation of the ATS switching module, the A ‘feed must be powered up prior to the B’ feed. Powering the feeds incorrectly will cause potential issues with the Automatic Switching Mode, Automatic Switching Mode is enabled by default, please check the ATS unit is configured correctly for your requirements.

### STEP 1

Site the unit in a suitable, stable location.

### STEP 2

Connect the unit to a suitable AC Power source, **Always Power On the A feed first to ensure correct operation**, Please ensure Circuit Breaker Protection, if required, is appropriate for the expected current requirements.

### STEP 3

Connect the Ethernet port on the unit, to either a PC / Laptop or Suitable Network Hub. N.B. The unit is supplied with DHCP enabled, (this means the PDU will automatically assign itself an IP address, in keeping with your network).

### STEP 4

To establish remote Monitoring, Connect the Ethernet Port on the Unit, to either a PC / Laptop or Suitable Network Hub, (Please note the Unit is supplied with DHCP enabled, this means the PDU will automatically assign an IP address in keeping with your network). The assigned IP address can be identified repeatedly pressing the ‘PUSH’ button. To scroll through various metrics including the IP Address.

### STEP 5

If an IP address is not assigned, the default IP address is 169.254.1.1

### STEP 6

Enter the assigned IP address into the web browser on your PC / Laptop (For best results we recommend using Google Chrome).

### STEP 7

Enter the default user name and password (User Name = admin, Password = admin). You will now be able to access the web browser for the unit you have selected, you will be able to Measure and Monitor all PDU Energy Metrics, set thresholds and begin to receive alarm notifications.

### STEP 8

Go to the configuration and set up Client Name, Location and Cabinet ID. Set up your own Static IP Address and email settings for alarm notifications.

### STEP 9

Basic installation is now complete, further configuration may be required to suit your specific requirements.

**Default IP Address 169.254.1.1 Default Subnet 255.255.255.0**

For further information, product registration, and to receive our MiB File or our free of charge management software (PDU SNMP Agent) please contact [technical@ipdu.co.uk](mailto:technical@ipdu.co.uk), quoting your product serial number / part number.